# **UTAC SERIES QUICK REFERENCE GUIDE**

# **UTAC SERIES QUICK REFERENCE GUIDE**

#### **KEYPAD CONTROLS**

SCROLL UP

CENTER

BUTTON

(SELECT)

#### DIGITAL ZOOM

Press the Digital Zoom button to cycle through the digital magnification settings.


# POLARITY

Press the Polarity button to reverse the color of the temperatures viewed in the display. (Monochrome and Alert color modes only)

SCROLL DOWN

### DISPLAY BRIGHTNESS

Press the Display Brightness button to cycle through increasing level of display brightness.



## MENU OPERATION


- 1. Press and hold the center button for 3 seconds to enter the menu system.
- 2. Scroll through the menu options using the front and rear buttons.
- 3. Select a menu option using the center button.
- 4. The menu mode will time out after 7 seconds of non-use, except in Adjust sub-menu.

### CAMERA OPERATION

- 1. Hold the center button until the menu appears.
- 2. Scroll and select IMAGE.
- 3. Select CAPTURE to enter the camera mode.
- 4. Press the center button to take a picture and advance the counter located in the upper left corner of the screen.
- 5. Exit the Camera mode by holding down the center button and selecting CAPTURE or powering down the unit.







#### ACCU-ZOOM ALIGNMENT

Perform this one-time step to align the UTAC digital zoom to your day optic cross-hair. The thermal unit may then be removed and reattached as a true clip-on. ACCU-ZOOM alignment will remain until the weapon or day sight is changed. US Patent Pending.


### ACCU-ZOOM PROCEDURE

- 1. Place the UTAC ahead of the day sight on the Picatinny (1913) Rail.
- 2. Ensure the UTAC is in 1X digital zoom mode with the lens cap closed.
- 3. Looking through the day sight, select AZ from the RETICLE menu so the dot reticle appears.
- 4. Select the ADJUST menu so the horizontal and vertical axes are showing.
- 5. Align the dot reticle horizontally (H) and vertically (V) with the center of the day sight reticle by using front and rear buttons.
- 6. Select EXIT.
- 7. The UTAC is aligned to the day optic for both 1X and digital zoom imaging. NOTE: The dot reticle may be turned off if desired. Select OFF from the RETICLE menu.





# UTAC SERIES QUICK REFERENCE GUIDE



# UTAC SERIES QUICK REFERENCE GUIDE

### CAUTION

THE THERMAL FOCAL-PLANE ARRAY OF THE UTAC IS SENSITIVE TO EXPOSURE TO EXTREMELY HIGH LEVELS OF RADIANT FLUX. NEVER EXPOSE THE UTAC EITHER POWERED OR UN-POWERED, DIRECTLY TO THE SUN OR ANY OTHER SOURCE OF RADIANT FLUX THAT THE HUMAN EYE CANNOT TOLERATE.

#### BATTERY INSTALLATION

Remove the battery cap and insert two CR123 batteries into the battery compartment with the positive (+) terminals facing out. Hold the Display button down for 3 seconds to check the battery life of the unit.

#### **POWERING ON/OFF THE UTAC**

To power ON the UTAC, simultaneously press and hold the Center and Rear buttons for 3 seconds. To power OFF the UTAC, simultaneously press the same buttons.

#### THERMAL CALIBRATION

Simultaneously press the Front and Center buttons while the lens cover is closed.

### UTAC WEAPON MOUNTING

Position the UTAC in front of the day scope. Use the coupling hood to eliminate stray light between the two sights.



**NIVISYS**<sup>\*\*</sup>